

### ILLUSTRATED

# CATALOGUE AND PRICE LIST

## ELEGARIGAL

## Apparatus and Supplies

MANUFACTURED AND FOR SALE BY

A. F. FLEISCHMANN, ELECTRICIAN.

ELECTRIC WORKS,

1226 Chestnut Street, Philadelphia, Pa.



PHILADELPHIA

THE ALDINE PRINTING HOUSE, 716 FILBERT STREET.

1884.

#### PREFACE.

Having had an experience of thirteen years in the manufacture of Electrical Apparatus and the repairing of many makes of Instruments, I am enabled to present to the profession and public generally Electrical Apparatus of practicavalue, constructed in a manner as to be durable, economical and to produce the best effects. The prices are low for first class Instruments, and much is saved in buying such than "cheap" (?) inferior Instruments.

than "cheap" (f) interior instruments.

I invite correspondence on any matter relative to the electrical science connected with the business, and will cheerfully give all information desired, within my power to pre-

sent, as a practical electrician.

## PURCHASERS' NOTICE.

All Instruments herein described, of less than four pounds weight, will be sent to any point in the United States by mail, postage prepaid, upon receipt of Catalogue price (eash with order).

All orders will receive prompt attention, and, to insure ne delay in shipments, full shipping instructions, with the name

town, county and State, must be given.

Remittances are to be made with the order by P. O. Money Order, Draft on Philadelphia or New York, or Registered Letter. When ordered to be sent C. O. D., one-third of the anount is to accompany the order.

I find it unnecessary to mention testimonials in my Catalogue, preferring the apparatus to merit the sale. I could fill a book with references, if I desired.

The prices are subject to change without notice.

Liberal rates to dealers.

#### IMPROVED GALVANIC BATTERY.



This Battery is the most convenient for the practice of hysicians for office and call use now manufactured. The lements used are zinc and carbon. The fluid used is bi-chro-ate of potash solution (see page 13). It is so constructed that any part may be examined, or necessary attention, such a replacing of plates, refilling, etc., can be done by any one vilbout trouble. The apparatus is arranged with ten, twenty r thirty cells. The cells are made of hard rubber, which are asped by metal bands in series of tens, so that in case of one eding injured it can be replaced conveniently at a small cost, or requiring a whole series of cells to be supplied. The ries can be lifted from the tray to empty and recharge, ither series of elements may be used, combined or independently, so that when using less than the full number there a saving of plates and fluid in the remaining cells.

So as to vary the intensity or the quantity of current, the alf or whole depth of the cell can be used at pleasure by awing up the tray-rods and securing them at a desired evation by means of a small lever, which act immerses the plates in the cells. The elements are connected for use by means of plug end cords, which are easily adjusted, one cord being bifurcated so as to prevent a shock to the patient by the

change of the number of elements attached.

A great advantage over other makes of batteries is to be able to use your battery if one cell is out of order. This can be readily done, as you can connect your elements at any point desirable, or loop the connections of the injured cell. Unscrewing a thumb-nut on the tray-rod, the series of plates may be taken from the case and easily examined.

By removing a screw holding the element-bracket in position, the zinc and carbon plates are readily removed or attached. The drippings of the plates, that cause much annovance, are received by a shallow trough arranged on the top of the hydrostat, in which space blotting paper may be placed to absorb the liquid; this is generally not provided for. For the convenience of transportation, the hydrostat is placed over the top of the cells, which is pressed down by rods and held firmly when the lid is closed. The lid of the case is hinged at the side, instead of at the back, to avoid the Battery being top-heavy and easily upset; it is divided in two parts, the one for the commutator and the other for the electrodes.

The plates have an acting surface of 81 square inches each, giving a good current, and power equal to twice the number of cells of some makes of batteries.

The ten cell Batteries are chiefly used for the eye, the ear, the nasal cavity for catarrh, the uterus, and electrolysis of small tumors.

With a twenty cell Battery a physician can treat almost any case, but with a thirty cell Battery, or a ten cell and a thirty cell Battery, making forty cells, a physician has as much current at command as he may ever need for rare cases.

If a power of forty, fifty or sixty cells is desired, it is advisable to purchase two batteries and connect them, as you will find a single large one will be unhandy for transportation. An interrupter handle, a pair of universal handles, cylinders, sponge discs, and silk cords accompany each Battery,

All metallic parts are finely nickel-plated.

Price,	complete,	10	cells							\$25	00
- 11	11	20	- 66							45	00
	11										
Calmai	0000000									5	00

A. F. FLEISCHMANN, 1220 Chestnut St., Ph	uu.	3
Automatic Rheotome	\$10	00
Fleischmann's Electrical Pendulum Rheotome	20	0.0
Combination Battery (that is, Galvanic and Faradic)		
with the No. 1 Faradic instrument, extra	25	00
With the No. 2 Faradic instrument, extra		

In many cases it is convenient to have them combined, but I should recommend persons to procure them separately, as often they need but the one at a time.

My galvanic batteries are the most complete now made.

All Makes of Galvanic Batteries Repaired and any Special

#### FARADIC BATTERIES.

## FLEISCHMANN'S PENDULUM FARADIC BATTERY.

DOUBLE CELL

This Battery is designed for the physician's office and call use. It fills a long sought-for want. I have made a series of experiments with the interrupters for Batteries, so as to be able to control the interruptions of the curruptions of t



rent, to have them uniform, regular and soft to the sensation, so as to be able to interrupt the current at about eighty up to several hundred per minute.

At last I succeeded to invent what I call a Pendulum Interrupter, by which I am able to produce the wished for terrupter, by which I am able to produce the wished for producing similar interruption are, when the interrupter is at rest, it is nearest to the point of attraction to a magnet, which produces the movement of the pendulum. There are no loose confections, like at axle points, etc., and it requires less battery power than any other to keep up the interruptions. The instrument has also a very quick interrupter attached, either of which can be used. Both or one of the cells may be put in action, according to the power desired.

The convenience of having two cells is, should the one run down in power the other can be substituted, or should both

be weak they can be used together.

This instrument has an extra secondary coil of great intensity, besides the ordinary coils: The primary and galvanic, the secondary, the secondary of great intensity, the combination of the secondary and secondary of great intensity, or the combination of the first three currents, either of which is connected for use by means of the switch, and the polarity changed by means of the commutator.

Nore—By primary and galvanic current, I mean that the Battery is arranged to have the galvanic current of the number of cells used in the primary current, this current will decompose. The zinc, after being amalgamated, requires very little attention. The Battery cell, for convenience of use, is the same as used for my single cell Pendulum Faradic Battery

All metallic parts are nickel-plated. The instrument, with universal handles, sponge discs, cylinder handles, foot-plate, etc., accompany the Battery, enclosed in a polished walnut case 10x74x64 inches.

#### SINGLE CELL FARADIC APPARATUS.

No. 1. Fleischmann's Pendulum Battery.

This Battery is constructed similar to the Double Cell Battery. It is smaller, without the extra secondary coil of great intensity, but one cell, and without the switch. The Battery has six currents, which differ in galvanic, magnetic, inductive and electrolitic effect. The polarity of these currents may be changed during application, by means of the commutator.

The Battery cell is arranged fluid-tight, and not requiring the emptying of the fluid after use, thereby preventing the spilling and bottling of the solution. The solution used to charge the cell is bi-chromator of potash (see page 13). The zinc plate requires no attention after first amalgamated, and when not used is placed in a small cup, in which about an ounce of mercury is put, which produces a good coating of If the plate is used up it can be replaced at a small amalgam. expense. When the Battery is to be used, the rubber cork is drawn from the aperture in the top of the cell the zinc is dropped into the solution, and connected at its proper post.

I have tested these battery cells, and have found them to run the instrument, without much variation of power from five to eight hours continuously; as in most cases they are used but one-quarter hour at a time, they will work satisfactory three to four weeks with a single charge of solution

costing but ten cents. The cords have plug ends attached, which fit firmly in the sockets of the battery poles and handles.

All metallic parts are nickel-plated. The Battery is put up in a polished walnut case, with universal handles, sponge dises and silk cords.

#### No. 2. FARADIC BATTERY.

No. 2 Battery is the same in construction as the No.1, with the exception of my pendulum interrupter and no foot-plate.

Price. . . . \$20 00

#### No. 3. Faradic Battery.

commutator. With universal handles cylinders and sponge discs. Weight 41 lbs. Price, . . . . \$15 00



No. 4. Family Faradic Battery.

This Battery is the same as the No. 3, but brass finish and plain attachments.

#### NO 5 SIX CURRENT FAMILY BATTERY.



No. 5 FARADIC BATTERY.

This Battery is operated by the Smee Cell, using diluted sulphuric acid for solution (see page 13). The six currents differ in galvanic, magnetic, inductive and electrolitic effect. Plain attachments accompany it.

Price, . . . . . . \$10 00

#### No. 6. FAMILY FARADIC BATTERY

This Battery is more powerful than the No. 5, and has six currents, same as No. 1, with Smee Cell. All parts nickel-plated.

Rubber Battery Cells are used, and they are constructed in a manner to be a very convenient form of instrument.

Price, complete, . \$15.00



#### IMPORTED POCKET FARADIC BATTERIES.



NO. 7. GAIFFE BATTERY.

The current is received from two cells, consisting of a zinc and carbon element. The exciting chemical consists of bisulphate of mercury dissolved in water. The vibrator by means of a lever, can be disconnected, thus stopping the current at will; by the same lever the interruptions may be produced by the pressure of the hand on it. The case, opening with two lids endways, is made of polished mahogany, size 71 inches long, 4 inches wide and 11 inches thick, weight 11 pounds, with cylinders, insulated bandles, silk cords, an oval insulated stem electrode, ball electrode, brush electrode and bi-sulphate of mercury accompany the Battery.

#### No. 8. GAIFFE BATTERY.

This Battery is the same as No. 7. Case 61 inches long, 4 inches wide, 11 inches thick, and has one lid. With cylinders, insulated handles, silk cords and bi-sulphate of mercury.

The Gaiffe Batteries, although small, are powerful, owing to the fineness of wire and silk insulation employed in making the helix. They have been in use a great many years.

are neat in construction, give off no perceptible fumes, can be started within a minute, and replaced in the pocket in the same time One charging of the cells will maintain a current for one hour. As a powerful Pocket Battery it has no equal; still

the larger Batteries are more durable and run longer with a single charge.

Extra Zines, per pair . . . . . . . . . . . . . \$ 25 Bi-sulphate of Mercury, per oz. 10c . . . . . lb. 1 25 Extra Rubber Cup, Double Cell . . . . . . . 1 50

#### No. 9. FRENCH BATTERY.

This Battery is similar to those before described, but smaller, 4<sup>3</sup> inches long, 3 inches wide, 1<sup>1</sup>/<sub>2</sub> inches high, has a single cell, complete with silk cords, cylinder handles and bisulphate of mercury.

#### MAGNETO-ELECTRIC MACHINES.

No. 10,



The current is produced by turning a lever, which puts in motion gearing, diving at a rapid rate, by means of a belt, a n agnet before the face of a permanent magnet. No chemical is used. The current produced by all makes of this style of machine is not as pleasant to patients as the Faradic Batteries.

#### "NEFF" MEDICAL BATTERY.

No. 11.

This Battery I make specially for a few customers who have used them some time. The cell used for action is on the principle of the Grove Battery, namely: zinc cup, porous cup and platinum strip; diluted sulphuric and nitricaeds are used, or a sulphate of copper cell may be used, composed of a copper box and a zinc plate, charged with dissolved sulphate of copper.

A. F.	FL	EISC	HMA	NN,	1223	Chestnut	St.,	Phila
-------	----	------	-----	-----	------	----------	------	-------

	-		400	.,,	**		 · A	166	ace.	
Price, complete, brass finish .									\$15	01
Zinc cup for Grove Cell									1	5
Porous cup " "						,				2
Platinum and connection for G										
Copper box									2	5
Zinc plate, square, size 5 in.x	31	x21							1	5
" " " 4 in.x	3	x24							1	2

Estimates given for any form of Electro-Medical Batteries, and a specialty made of repairing all makes.


#### SUPPLIES FOR GALVANIC AND FARADIC BATTERIES.

Rubber cup, 4½ in. high x 1 in. x 15-16 in., each \$	4
Carbon plates, each	9
Zines for Galvanie Battery, each	1
Zines for Faradic Battery, each	9
Zincs by the dozen at a reduction.	
Jar with cemented ring for Faradic Battery	7
Bi-chromate Battery Cell, same as described page 4, for	
Faradic Battery, brass	2 7
Bi-chromate Battery Cell, same as described page 4, for	
Faradic Battery, nickel-plated	3 0

## CONDUCTING CORDS.




1½ yards Silk Tinsel Cord, with improved plated tips, per pair
per pair .  1½ yards Cotton Tinsel Cord, with improved brass tips, per pair .  2 yards Cotton Tinsel Cord, with improved brass tips,
per pair
1 yards Plain Cord, per pair
2 yards Plain Cord, per pair
Rubber Covered Cord, very suitable for Bath purposes,
per pair



Great care is taken in making the Electrodes of the best material and shape.

	material and onapor	
No. 1.	Universal Handle, hard rubber, with open	
	circuit-breaker attached, nickel-plated, each \$1	5
11.	Same as No. 1, but closed circuit-breaker, each 1	7
2.	Same as No. 1, polished walnut, each 1	0
21.	Same as No. 11, polished walnut, each 1	5
3.	Universal Handle, without circuit-breaker,	
	nickel-plated, each	7
31.	Short Universal Handle for plug connections,	
	per pair	7
4.	Cylinder Handles, nickel-plated, per pair 75 and 1	0
5.	" brass, per pair 60 and	7
6.	Sponge Discs, nickel-plated, each 20 to	5
7.	Universal Sponge Handle, each	7
8.	Foot Electrode, copper, 42x92 inches, each	6
9.	Same as No. 8, nickel-plated, each	8
10.	Foot Electrode, copper, 8x91 inches, each	8
11	Como as No 10 niekol plated sach	0



	Double Bladder Electrode, each 2 50
15.	Urethal Stricture Electrode, each 1 00
16.	Dental Electrode, each 1 00
17.	Ear Electrode, each 1 00
174.	Ear Electrode, speculum shape with adjustable - 4
	Stem each

DE.


No. 12.

13.

#### FIFCTRODES

Rectum Electrode, each . . . . . . . . . . . \$1 40

Bladder Electrode, each . . . . . . . . . 1 40



No. 18. 19. 20. 21. 21. 22. 23.	Laryngeal Electrode, external use, each     \$2 00       "internal use, each     1 50       Tonsillitis Electrode, each     1 50       Eye Cup Electrode, each     1 50       Double Eye Glass, adjustable     6 00       Tonsil Electrode, each     1 50       Sponge Cups, per pair     75
	ELECTRODES.
-88	No 2.5.
400	N9.27
	No.21
	No.5;8
	No.30
No. 24. 25. 26. 27. 28. 29. 30.	Scourge Brush, each     .50 to   \$1 00   Tongue Electrode, with insulated section for the teeth, each     1.25 to   1.75   Fauce's Electrode, each     1.25 to   1.75   Ulcer Electrode, different shapes, each   .50 to   1.50   Nasal Electrode, each     .50 to   1.50   Uaginal Electrode, each     .50 to   1.75   Uaginal Electrode, each     .50 to   1.75   Cup for mouth of Womb, each     .50 to   1.75

Sponge Holder, hard rubber, with metal socket,

" in sets of 2, 4, 6, 8 or 10, insulated, except on point . . 2 00 to 12 00

34

35.

36.

1 00

1 25

## No. 37. Sponge Holder on side of handle, walnut and

	metal so	ocket,	each				. \$1	50
38.	Same as No	). 37,	with	rubber	handle,	each	. 2	00

- 39. Bath Sponge Holder, large handle, each . . 2 50 40. Galvano-Cautery Electrodes, each . . 1 50 to 7 50
- 41. Set of six Electrodes . . . . . . . . . . . . . 10 00 42. Galvano-Cautery Electrode Handles,

42. Gaivano-Cautery Electrode Handles,
each . . . . . . . . . . . . 2 00 to 5 00
Sponges, each . . . . . . . . . . . . . . . . . 10 to 30
Set of Electrodes, in fine velvet and morecee case 12 00

#### CONTENTS.

No.	3.	Universal Handle.	No.	23.	Sponge Cup Elect	rode.
- 11	12.	Rectum Electrode.			Scourge Brush "	
11	13.	Bladder "			Nose	

" 13. Bladder " " 28 Nose " " 17. Ear " " 29. Intra-Uterine " " 21. Eye " " 30. Vaginal "

All the Electrodes are heavy nickel-plated, and, where necessary, insulated by French gum or hard rubber.

Any description of Electrodes made to order.

#### BI-CHROMATE OF POTASH SOLUTION.

(Electropoion Fluid.)

For the Faradic Battery, Grenet Cell, Bunsen Porous Cup, etc.—To three pints of cold water add four fluid ounces of sulphuric aid; when this becomes cold mix it with bichromate of potash, finely pulverized, about four ounces; also add a few drops of nitrie acid. Mix it well.

For the Galvanic Battery, Motor Battery Cell, Grenet Cell, etc.—Mix with the above four drachms of bi-sulphate of mercury dissolved in a half pint of water. This solution keeps the zinc amalgamated.

#### DILUTED SULPHURIC ACID.

For Smee Cell and Bunsen Battery.—Mix twelve to fifteen parts of water with one part of sulphuric acid (fluid measure). Allow the mixture to cool before using.

NOTE.—When mixing the sulphuric acid with water, pour the sead in the water, half the quantity at a time, using glassware. Be sure not to pour the water in the acid. By doing so the glass will not break, as often it does from the heat produced by mixing suddenly.

#### INDUCTION COILS.



Induction Coil, with automatic interrupter, giving a	
spark of 1 inch	00
Induction Coil, with automatic break and commutator,	
giving a spark of 4 inch 8	00
Induction Coil, with automatic break and commutator,	
giving a spark of \frac{1}{2} inch	00
Induction Coils of Large Size made to order.	
6-inch Geissler Tube, each	74

#### NEW TOEPLER-HOLTZ ELECTRICAL MACHINE.



No. 1.

No. 1. New Toepler-Holtz Electrical Machine: gives long and brilliant discharges, self-charging, works in all weather. Diameter of revolving plate 26 centimeters==10\frac{1}{2} inches, giving 5-inch spark. Mounted on finely polished base Price, \(\frac{2}{2}\)5.00. No.2. New Toeplor-Holtz Electrical Machine: self charging, more finely finished than No.1, fitted with rubber supports, with neat and new arrangement for adjusting the combs, etc., to the plates; also, with the adjustments for the plates. Diameter of revolving plate, 31 centimeters—about 12½ inches. Price, \$50.00.

No.3. New Toepler-Holtz Electrical Machine: self charging and finished same as No.2, and fitted with rubber supports, with neat and new arrangement for adjusting the combs, etc., to the plates; also, with the adjustments for the plates. Diameter of revolving plate, 41 centimeters—about 16½ inches, \$80.00

No. 4. New Toepler-Holtz Electrical Machine: self-charging, finished same as No. 2, and fitted with rubber supports, with neat and new arrangement for adjusting the combs, etc., to the plates; also, with adjustment for the plates. Diameter of revolving plate, 52 centimeters—about 21 inches, \$115.00

Nos. 2, 3, 4 are elegantly mounted on polished mahogany base, with Geissler tube attachment, conical bearings for rubber supports, etc., etc. They are very popular on account of their elegance of design, fine finish (a very important point where electricity is used at such high tension, as in the Holtz machine), convenience and adaptability to the purposes intended, and, above alt, on account of their constancy of action, etc., etc. New Toepler-Holtz will undoubtedly be the machine of the future.

#### IRON BASE BELLS.

They are found to be substantial and easily adjusted. They give a very loud sound, and are used in schools, offices or dwellings (acoustic telephone lines), also as Burgiar Alarms. Single stroke or Vibrating Bells.

These Bells are made in the best manner for the prices, and will be found fo work very satisfactory.



#### DDICE OF IDOM DACE DELLE

																Nickel-	plate	ed
2	incl	h Vil	bī	at	in	or .	or	Si	gn	al	B	ell		\$2	00	\$2	50	
3	1 11			E.E					"			44		2	25	2	75	
4	inch	Bell												3	50	3	75	
5	44	11												4	25	4	75	
6	11													5	25	6	00	

Larger sized Gongs made to order.

#### FLEISCHMANN'S ELECTRIC BELL OUTFIT.



Electric Bells are more easily put in than the ordinary pull mechanical bells After reading through our directions. which accompanies each outfit, you are able to

please, with sure success.

#### OUTFIT NO I

Including good Battery Cell, polished Bell on walnut

base, polished ash or walnut Push Button, fifty (50) feet double insulated copper leading wire, chemicals, etc., and all necessary directions for putting in any house, or from house to house.

#### OUTFIT No. 2

Price, complete . . . . . . . . . . . . . \$4 25. Including large Battery Cell, 31-inch Bell on japanned

iron base frame, with nickel-plated cover, polished ash or walnut Push Button, seventy-five (75) feet double Insulated leading copper wire, chemicals and all necessary directions.

Sm	all V	ibrating	Bell, on	W	00	d	ba	se					\$1	00
21	inch	Walnut	Box Bell										1	50
3	4.6	16	- 11										1	75
31	**	11	11										2	00

#### WOOD BOX BUZZARS.

The Buzzar is meant to be used in cases where a person is to be signalled without causing general attention.

Price.... \$2 00

#### IMPROVED ANNUNCIATORS.

STYLE NO I For Private Residences.

Banks, Offices. &c.

This is a new style drop Annunciator. There is no name or figure indication visible until the made connection causes the drop indication to appear, thereby avoiding the confusion which necessarily takes place if all the indications are visible. After the indication appears it can be



adjusted by a simple lever. The bell and magnet are mounted on a metal base; in this way they are not affected by the warping or swelling of the wood. They are furnished in walnut or ash cases.

4	Indications,	including	Bell						\$17	00
6	11		- (1						20	
7	11	"	11						23	
8	11	11	**						25	
9	11	"	11						27	
10	11	11	11						30	
	00 0	O antua Can	1	33		- 1			00	00

#### 00 extra for each additional number

#### STYLE No. 2.

4	Indications,	complete							\$13	0.0
6	"	11							16	0.0
8	11	11							19	00
9	11								21	
10	11	11							00	0.0

#### STYLE NO. 3. ANNUNCIATOR BURGLAR ALARM.

The Annunciator is arranged as before mentioned and in addition has a continuous ringing attachment, so that if a room is entered by a window or door the indication drops and remains so; the bell also keeps on ringing till switched off. It is also arranged with a silent test.

4	Indications,	complete								\$25	0.0
6	11	û								31	00
8	"	**			٠.					37	00
9	11									40	
10	11	11								43	

18 A. F. FLEISCHMANN, 1226 Chestnut St., Phila.

## MATERIALS FOR BELLS, ANNUNCIATORS, &C.

Push Buttons, bl'k walnut \$	2
" " ash	2
" " rosewood .	30
Bronze Push Buttons	51
" " with	
"Push" on button	7
Nickel-plated Push Button	7
" with "Push" on button . 1	01
Push Buttons of special designs made to order.	0
Improved Burglar Alarm Door Springs, each	3
" Window Springs, each	31
" " plain, per pair	1
Bronze Door Pulls 2 00 to 3	5
Double-pointed Tacks, tinned, per box 10 to	5
Ornamental Brackets, per pair	9
Lightning Arrester and Ground Switch, on wood base	2
	4
Porcelain Insulators, for line, with screws, per doz. 25 to	
All styles of Keys, Bell Pulls, etc., made to order.	
SWITCHES.	
Circular, walnut base, 1 connecting point \$	3
" " " 9 " " ,	4
	4
" with posts, 1 connecting point .	9
	1
Hard rubber base, 1 connecting point	6
	6
" " 3 " "	7
" " with posts, 1 and 2 connecting points	9
" " " 3 and 4 " " 1	U
MAGNETS.	
Electro Magnets, common	2
with rubber flanges 1 00 to 3	0
Magneto Machine Magnets, 4 inch	7
" " " " " " " " " " " " " " " " " " " "	. 5
	5
Polished Cast Steel Bar Magnets, 4x8x4 inches	3
" " $\frac{1}{4}x_4^3x_6$ "	5
Magnets any shape or size to order.	

#### GALVANOMETERS.

Galvanometer, with Astatic Needle, on rosewood base. with leveling screws. graduated circle and glass

cover . . . . . . . . . \$15 00 Detector Galvanometer, ho-

rizontal. . . . 3 00 to 6 00 Detector Galvanometer, vertical . . . . . 10 00 to 25 00





#### INCANDESCENT ELECTRIC LAMP.

Swan's Incandescent Electric Lamp, 1 to 20 candle power, with patent spring holders, same as used in London, \$4 50

Incandescent Electric Lamp, of platinum, gives a brilliant light, with 3-quart cells, and isused for illustration . \$4 50

#### RATTERIES

SMEE BATTERY.

The Smee Battery elements are two zinc plates, between which a platinized plate is held by a clamp.

This Battery is used mostly for Electro-Medical Apparatus. namely, the Kidder, Glass and many other makes. It is charged with diluted sulphuric acid in the same proportion

Cell, complete				40	0
complete				402	U,
Zinc (rolled), 21 and 41 inches, per pair					4
Platinized Silver Plate and connection .				1	01
Zinc Clamp					
Jar, with lip					34



This Battery is adopted by most Telephone companies; also, for open circuit use, mainly Electric Bells, Burglar Alarms, etc., on account of being more easily kept in order, as the compressed prisms can be readily renewed at less expense than the porous cups in the old style cells. It is not as constant as the other Batteries, but does remarkably well for the above purpose. It requires little attention, say once every three to twelve months. Sal-ammoniac and water is used in the jar.

\$1 6
1 00
50
20
19
15
8

#### DANIELL'S BATTERY



Fer Cell, complete, Glass Jar\$1	50
Coppers, with pockets	50
" Shells	45
	25
Porous Cups, per doz , No. 1 2	00
" each	20
	35
	00
	35
Zinc Clamps	20

20 This Battery is used mostly by Electro-Platers and for experiments. The current is very constant.

#### GROVE BATTERY.



Cell, complete,	287	cn					÷						٠							\$1
Cell, complete, i	$\mathbf{n}$	84	21	8	. 6	C														1
Platinum Strips																				
Porous Cup																				
ar																				
Zinc																				

This Battery is used mostly for experimental purposes, electric light, etc. Its power is greater than the Bunsen Cell. Nitric acid is used in the porous cup, and diluted sulphuric acid about the zinc.

#### CARBON BATTERY.

	No. 1.	No. 1%. 41/4×41/6 it
Cell, complete		81 60
Zinc	40	50
Connector for Zinc	15	15
Carbon	12	35
Clamp for Carbon		15
Porous Cup	. 12	12
Jar		25
Platinum-faced Connection	. 22	22

#### BUNSEN BATTERY.

The Bunsen Battery being very powerful and producing a constant flow of current, is mainly used for electro-plating, electro-motors and by dentists for the electric plugger.

The acids used are nitric acid, or, if wished, bichromate of potash solution may be used in the porous cup—its use obviates the funce which naturally are caused by nitric acid, but the current produced is not quite as powerful and diluted sulphuric acid (see page 13) used in the jar. The fluids are to be at the same height.



Cell, complete	75
	50
Carbon Connection	70
Glass Jar 13 20 25 30	35
Porous Cup	25
Zinc and Connection	00

Rolled zincs are used in my make of Carbon and of Bunsen Batteries, and are found far superior to the cast, as they are solid, not having air or sand holes. They last longer and can be easily amalgamated. There is less local action in the cell.

#### SOLUTION FOR AMALGAMATING ZINCS.

Mix one pound nitric with two pounds of hydrochloric seld, and add eight ounces mercury. When the mercury is dissolved, add three pounds more hydrochloric acid. To amalgamate the zinc, immerse lit in his solution for one or two seconds, then remove it quickly to a dish of clean water, and rub it with a breach or cloth. This solution can be kept in a covered far and used many time.

#### GRENET BATTERY.



The Grenet Battery is a clean, portable cell. The elements are two carbon and a zinc plate. Bi-chromate of potah stolution is used to charge the cell. When charged is used to charge the cell. When charged zinc is connected to a brass not by which it can be immersed or drawn from the zinc is connected to a brass not by which it can be immersed or drawn from the distribution of the property of the

#### CELLS COMPLETE.

No.	1.	6	inches	high,	1	pint			82	00
44	2.	. 8	11	11	1	11			3	50
		. 10		66	1	quart			4	50
11	4	12	66	11	2	- 11			5	00

#### CALLAUD, OR GRAVITY BATTERY

The Callud, or Gravity Battery, is adapted for close or open circuit, has a constant current and requires very little attention. It is used on telegraph lines, electric bells, etc., and in a series fifty to one hundred and fifty cells for a perma neat Galvanie Battery for physicians' office use.



		No.2. Main or Local 6x8 in.
Cell, complete	\$ 90	
Zinc	30	35
Copper	18	20
Tripod Hanger	20	20
Jar	30	35

Estimates given for Batteries by the Quantity.



Red and White Braided, Paraffined and Compressed Cotton and Linen Double Covered Office Wires--Fine Finish.

No.	12.	35 feet,	per pou	nd.					ŏ
41	14.	52 "	- 11						ä
66	16.	90 "	66						ŏ
- 61	18.	132 "	66						5
		These	wires in	onv	other	color at	the same	prices	

#### BURGLAR ALARM, CALL BELL AND ANNUNCIATOR WIRE. Double Cotton Wrapped, Waxed and Paraffined.

## 200 "

#### 4 10 " 20 239 " KERITE COVERED WIRE.

Size of Copper Core.	Outside		er in Fra ces per f	ctions of a	n inch.
Stubs' Gauge.	3-32	4-32	5-32	6-32	7-32
No. 14		80 031	\$7 04½ 04 03	80 06 05	80 07

				GAL														
No.	0 to	9, 1	per	poun	d.													80
45	10 to	11.	6.0															
44	12.		61															
4	13 and	1 14	14															

#### PLIABLE CORD.

For Telephone, Medical Batteries, Pluggers, &c.

Silk Tinsel, per yard							80
Cotton Tinsel, "							
Silk, double, wire conductors, per yard							
Cords, worsted covers, double							
cords, worsted covers, double							

#### MAGNET WIRE.

Brown & Sharpe's American Gauge.

No.	B. & S. Gauge.	Cotton.	Silk.
. 14	.07196	8 45	
15	.05706	50	
16	.05082	50	81 12
17	.04525	60	1 12
18	.04030	60	1 12
19	.03589	65	1 13
20	.03196	70	1 12
21	.02846	70	1 20
22	.02534	75	1 30
23	.02257	83	1 42
24	,0201	90	1 56
25	.0179	1 00	1 81
26	,01594	1 10	2 10
27	.01419	1 25	2 25
28	01264	1 35	2 38
29	.01125	1 50	2 75
30	.01002	1 65	2 95
31	.00892	1 80	3 25
32	,00795	1 95	3 45
33	.00708	2 40	3 90
34	,0063	2 85	4 10
35	.00561	3 25	5 20
36	.605	4 37	5 85
37	.00445	4 01	11 00
38	.00396		13 00

We can guarantee all our wire to be about 98 per cent. and above of pure copper.

For numbers of feet, resistance, etc., see tables, pages 26 and 27.

The prices above are for quantities of one pound and upwards. 20 per cent. advance on ounce orders, and 10 per cent. advance on more than quarter pounds.

## Number, Diameter, Weight, Length and Resistance of PURE COPPER WIRE.

#### AMERICAN GAUGE.

	Diam.	Sp. Gr	ght. , 8.889.	Length		eet per proxi		Resista	nce of I	Pure Copper cenheit.
No.	Inches.	Grs. per Ft.	Lbs. p.1000 Ft.	Naked.	No.	Covered.	Silk Covered.	Ohms per 1000 Ft.	Feet per Ohm.	Ohms. per Lb.
7 8 8 9 9 100 111 122 133 134 145 156 167 222 233 224 225 227 288 29 29 20 33 34 355 26 36 37 388 39 440	14428 12849 11443 11443 10489 109074 107198 03708 03708 03589 03589 03589 03589 03589 03589 03589 03589 03589 03589 03589 03589 04525 04708 04525 04708 04525 0452	3.38 2.68 2.13 1.69 1.34 1.06 .84 .67 .53 .42 .34 .27	82,90 49,88 39,59 24,88 15,65 16,19 17,81 6,19 18,78 1	15,90 20,05 25,28 31,88 40,20 50,69 63,91 80,59 101,63 128,11 161,59 203,76 324,06 408,58 51,06 161,20 203,76 204,26 6002,71 819,21 1032,26 6002,71 819,21 1032,27 103	7 8 9 10 111 12 13 14 15 16 17 18 19 20 21 22 23 24 25 27 28 30 31 32 33 33 34 35 36 36	422 555 68 87 7100 7100 7100 7100 7100 7100 7100	466 690 757 955 1290 1300 305 300 490 490 490 1285 1570 2480 3920 4930 4930 1970 2480 4930 1970 1970 1970 1970 1970 1970 1970 197	2.084 2.628 3.314 4.179 5.209 6.645 8.617 10.506 13.323 16.799 21.185 26.713 33.684 42.477 53.563 67.542 85.170 107.391 135.402 170.785 170.785 2215.312 221.583 342.443	1928.75 1529.69 121213.29	.00824 .010113 .020113 .030113

### TABLE SHOWING THE DIFFERENCE BETWEEN WIRE GAUGES.

Diameter in Inches.

Number.	London.	Stubs'.	Brown & Sharpe's
7	.180	.180	.14428
8	.165	.165	.12849
9	.148	.148	.11443
10	.134	.134	.10189
11	.120	.120	.09074
12	.109	.109	.08081
13	.095	.095	.07196
14	.083	.083	.06408
15	.072	.072	.05706
16	.065	.065	.05706
17	.058	.058	.04525
18	.049	.049	.04030
19	.040	.042	
20	.035	.035	.03589
21	.0315	.032	.02846
22	.0295	.028	
23	.027	.025	.025347
24	.025	.025	.022571
25	.023		.0201
26	.0205	.020	.0179
27	.01875		.01594
28	.0165	.016	.014195
29	.0155	.014	.012641
30	.0135	.013	.011257
31	.01225	.012	.010025
32	.01125	.010	.008928
33	.01025	.009	.00795
34	.0095	.008	.00708
35	.0095	.007	.0063
36	.0075	.005	.00561
37		.004	.005
38	.0065		.00445
39	.00575		.003965
40	.005		.003531
40	.0045		.003144

#### CARBON PLATES.

#### For Smee, Bunsen, Grenet and other Batteries.

L	ong.								V	Vi	de							,	Т	hie	ek						1	ri	ce.
6 i	nche	8.							27.4	i	DC	b							500	in		1.					- 00	60	12
6	66										64								à										25
6	64								3		£ 6								i		6								30
53	66										14								į		*								15
41	66										66								į		ú								11
41	41								18		4.6										14								10
04	-								13		66								3		i i								50
10	66								28												4								60
7									4										3										50
8	66								5		16			•							í.								45
9	66								A										3		4								60
9	6								a.	Σ									1										45
9									0										3										45
10	44								o										4										
8	6.6							.1	0		61																		75
10								1	2										j									1	25
12	66								6																				70
12	66							1	2		46								ą	,	44							1	25
																						١,							

Carbons of any length, width and thickness made or cut to order.

#### FLECTRO-MOTOR.



This Apparatus is quite a novelty, and pleasing for illustrating the force of electricity and magnetism. The fly wheel makes several hundred revolutions per minute, and by it a number of mechanical figures can be put in motion. The Motor, in connection with a half gallon Bunsen Battery, may be run for twenty to thirty hours continuously, to revolve a show table, a fan, etc.; or, in the laboratory

it may be utilized in different ways, for instance, for stirring liquids, etc. It will serve well where a small power is desirable. It is a cheap apparatus for schools, and makes an interesting present for young folks.

Price, complete, Motor with Battery Cell, solution for Cell, 

Solution bottle.... Zincs, per pair.... 10 Solution (see page 13) same as for Galvanic Battery.

#### BATTERY MATERIALS, ETC.

Bottles not included.

P. D. J. C.													
Rolled Zinc Plates, sizes containing													
Glass Jar for Faradia Pattern with 1													
Glass Jar for Faradic Battery, with b	rass ring	78											
Bi-chromate Solution, per lb		25											
Bi-chromate Solution, per 15		10 and 13											
Bi-chromate Solution, per gal		50 and 60											
Amalgam, for Frictional Machine, per		25											
Sulphate of Copper por ll.	0Z	10											
Sulphate of Copper, per lb		10											
Single Connectors, each		12 and 15											
-A		8 and 10											

Reductions made by ordering large quantities.

Repairing of all makes of Electrical Apparatus a specialty,

Supplies for Neff Battery and other makes on hand.

#### THE "RAPID" LEARNERS' OUTFIT.



We guarantee any person, young or old, with ordinary intelligence and diligent practice, with the above metioned "Rapid" Learners' Instrument Outfit to become competent operators.

"Rapid" Learners' Outfit, complete, with Battery, Book of Instruction, Wire, Chemicals, and all necessary materials for Sounder, on base...... 2 00 " Key, with table posts... 1 20
Cell of Battery, complete, large No. 1, 5x7.inch... 90 "Rapid" Learners' Instrument, without Battery, sent by mail, resistance, for use only on outdoor lines of from 200 feet to 10 or 15 miles in length, price, without Battery, etc........... 3 75 Same sent by mail, prepaid. 4 00
Rapid "Learners' Sounder, 20 ohms resistance, on base. 2 75 Battery cannot be sent by mail.

Equipment and cost of a local practicing or communicating line, indoors, where two instruments are within 100 feet of each other.

Regular "Rapid Learners" Outfits		87	50
11/2 lbs. Office Wire, extra, 225 feet			10
how Steel Stanles			12
No. 1 Extra Cell of Battery, 5x7			90
		90	97

Equipment and cost of an outdoor line of from 200 to 800 feet in length, with two instruments connected.

2 twenty ohm "Rapid" Learners' Instruments				87 5
4 to 10 Cells of No. 1 Battery, 5x7, each				9
6 to 10 Pony Insulators and Brackets, each				0
1 lb. Office Wire				
1 box Steel Staples				
200 to 800 feet No. 12 Galvanized Telegraph Wire,	pe	r 100	feet.	0

#### SUPPLIES FOR AMATEURS AND EXPERIMENT.

Hard Rubber Rods, Tubing, Sheeting, Cups, Magnet Heads, etc.
Brass Wire, Tubing, Rods, Sheeting, Machine Screws, etc.
Copper Wire, Steeting, Tubing, Rods, etc.
Iron Wire, Rods, Tubing, Sheeting, Machine Screws, etc.
Steel Rods, Wire, Sheeting, etc.
Platinum Wire, Sheeting, etc.
Silver, Gold, Iridium, Nickel, etc.

Prices given on application.

Gongs, Screw Plates, Taps and other Goods.

#### BOOKS ON MEDICAL ELETRICITY.


ALTHAUS-Medical Electricity	86	00
BARTHOLOW—Medical Electricity	2	50
BEARD & ROCKWELL-Medical and Surgical Electricity	6	25
ROCKWELL-Lectures on Electricity	1	25
BUTLER—Experience in Galvano-Surgery		50
BYRNE—Electro-Cautery in Uterine Surgery	1	25
DUCHENNE-Localized Electrization (Tibbit's translation)	3	00
Hamilton-Clinical Electro-Therapeutics	2	00
HAYES—Electro-Thermal Bath	1	25
IVES-Electricity as a Medicine and its Mode of Applica ion	1	00
	4	50
MORGAN-Electro-Physiology and Electro-Therapeutics	6	50
NEFTEL-Galvano-Therapeutics	1	50
POORE—Electricity in Medicine and Surgery	4	75
Prince—Galvano-Therapeutics	1	25
REYNOLDS-Lectures on the Clinical use of Electricity (American		
edition)	1	25
SCHWEIG-Galvanic Baths		50
SMITH—Lectures on Electricity.		75
TIBBITS-A Hand-Book of Medical Electricity		
		00

#### BOOKS ON ELECTRICAL SCIENCE.

ANDERSON-Lightning Conductors	\$6	50
Beechy-Electro-Telegraphy		40
Bell-Researches in Electric Telephony		60
CLARK & SABINE-Electrical Tables and Formulæ	5	00
CROMPTON—Electric Light for Industrial Uses		40
CULLEY—Hand-Book of Practical Telegraphy	6	00
CUMMING-Introduction to the Theory of Electricity	2	25
DAVIS & RAE-Hand-Book of Electrical Diagrams and Connec-		
tions.		00
DOUGLAS—Manual of Telegraph Construction	6	00
Dolbear-The Telephone (containing directions for making)		50
Du Moucel—Electro-Magnets		75
Edison-Edison, and his Inventions		75
FERGUSON—Electricity	1	50
FISHBACK—Elementary Treatise on Electric Batteries	2	50
GORDON-A Physical Treatise on Electricity and Magnetism	7	00
GORDON—Lectures on Electric Induction		80
Hedges-Useful Information on Practical Electric Lighting	1	20
HIGGS-The Practical Application of the Electric Light	3	50
HIGGS-Electric Transmission of Power	1	20
Hoskioer-Laying and Repairing Electric Telegraph Cables	1	50
INDUCTION COILS-How made and how used		50
JENKINS-Electricity		40
JENKINS-Electricity and Magnetism	1	50
JENKINS-Reports of Electrical Standards	3	75
Kempe—A Hand-Book of Electrical Testing		00
LANGDON-The Application of Electricity to Railway Working		50
LEVANDER-Magnetism and Electricity	1	00
LORING-A Hand-Book of the Electro-Magnetic Telegraph		50
MAXWELL-A Treatise on Electricity and Magnetism, 2 vols	8	00
POPE—The Modern Practice of the Electric Telegraph		00
Preece & Sivewright—Telegraphy		50
PRESCOTT—The Speaking Telephone, Electric Light, etc	4	00
ROGERS-Terrestrial Magnetism and the Magnetism of Iron Ships		50
Sabine—History of the Electric Telegraph	1	25
SCHWENDLER-Instructions for Testing Telegraph Lines		00
SHOOLBRED-Electric Lighting and its Practical Applications	2	00
SAWYER-Electric Lighting by Incandescence	2	50
THOMPSON-E'ementary Lessons in Electricity and Magnetism	1	25
TYNDALL—Lessons in Electricity	1	00
URQUHART-Electro-Plating	2	00
URQUHART—Electro-Moters	3	00
WATT-Electro-Metallurgy The above works, or any other books, will be sent by mail from	6	on

		PAGE
Annunciators		17
Battory Di Chamata	Jell	18
" Runsen	pell	9
	avity	22
Daniell's		01
" for "Ne	And the second s	21
" Leclanche	ff" Battery	8-9
Materials		20
	che	29
Bells and Outfits		16
Books.		31-32
Burgiar Alarms and Co	onnections	5, 17-18
Carbon Plates		16
Chemicals		28
Conducting Cords for M	Iedical Batteries	9
Combination (Galvanie	and Faradic) Battery.	· · · · · · · · · · · · · · · · · · ·
Electrodes	10 1	19.19
Electro-Magnets		18
Electro-Magnetic Batte	ries	, 7, 8-9
Faradic Batteries		28-29
French Pocket Battery		7, 8-9
Galvanic, Portable Bat	teries	1.2-3
Galvanometers		19
Holtz Electric Machine		. 14-15
Horse-Shoe Magnets		
Industion Coils		19
Insulators Posselain		
Lightning Arrester		. 18
Magneto-Electric Mach	ines	- 8
"Neff" Medical Batter	V.,,,,,,,,,,,	8-9
Pliable Cords		. 25
Push Buttons		. 18
Solution for Amalgama	ting Zines	. 22
Supplies for Ameteurs	and Experimenters	. 13
Supplies for Galvanic a	nd Faradic Batteries	. 9
Switches	Paradic Datolites	18
Static Machine		.14-15
Table of Diameter, Weigh	tht, Length and Resistance of Copper Wir	e. 26
Table of Difference in V	Vire Gauges	. 27
Telegraph Learners' In	struments	30
	Bell.	
		24
		E 10 17 L







A.D 1851